Hinweis CR0452

Anleitung, technische Daten, Zulassungen und weitere Informationen unter:

Bestimmungsgemäße Verwendung

- Einsatz unter erschwerten Bedingungen (z.B. erweiterter Temperaturbereich, starke Vibrationen, intensive EMV-Belastung)
- Einsatz als programmierbares Grafikdisplay zur Steuerung, Parametrierung und Bedienung von mobilen Maschinen und Anlagen
- Kommunikation mit anderen Systemkomponenten über CAN-Schnittstelle
- Keine Zulassung für sicherheitsrelevante Anwendungen

Montage

Geeignet für Materialstärken bis 3 mm.

► Ausschnitt erstellen.

► M52 Mutter vom Gerät entfernen.

► Gerät in den Ausschnitt setzen.

► Montagerahmen von hinten auf das Gerät setzen.

► M52 Mutter handfest auf das Gerät schrauben.

Inbetriebnahme

Das Gerät darf nur durch fachkundiges Personal in Betrieb genommen werden. Wir weisen zudem ausdrücklich darauf hin, dass jegliche Haftung ausgeschlossen ist, wenn die entsprechenden Hinweise in den Dokumentationen für die Inbetriebnahme und Programmierung nicht beachtet werden.

Zur Inbetriebnahme und Programmierung benötigte Komponenten:

Dokumentation	Software	Hardware
• Programmierhandbuch • Systemhandbuch	• Programmiersystem CODESYS	• CAN-Interface

03 / 2019

80283746 / 00

ifm electronic gmbh • Friedrichstraße 1 • 45128 Essen • Germany

Note CR0452

Instructions, technical data, approvals and more information at:

Functions and features

- Use under difficult conditions (e.g. extended temperature range, strong vibration, intensive EMC interference)
- Use as a programmable graphic display for controlling, parameter setting and operation of mobile machines and equipment
- Communication with other system components via CAN interface
- No approval for safety-related applications

Installation

Suitable for material thicknesses up to 3 mm.

► Make a cut-out.

► Remove the M52 nut from the device.

► Insert the device into the cut-out.

► Place the mounting frame onto the device from the back.

► Screw the M52 nut onto the device and tighten by hand.

Set-up

The device must be put into operation by qualified personnel.
Furthermore we expressly point out that any liability is excluded if the respective notes in the documentation for set-up and programming are not observed.

Components needed for set-up and programming:

Documentation	Software	Hardware
● Programming manual ● System manual	● CODESYS programming system	● CAN interface